




	LOAD CURVES WITH REGENERATIVE EXTENSION VALVE ENABLED
	LOAD CURVES WITH REGENERATIVE EXTENSION VALVE DISABLED (EES)




_____	<b>LOAD CURVES WITH REGENERATIVE EXTENSION VALVE ENABLED</b>
_____	<b>LOAD CURVES WITH REGENERATIVE EXTENSION VALVE DISABLED (EES)</b>




_____	<b>LOAD CURVES WITH REGENERATIVE EXTENSION VALVE ENABLED</b>
-----	<b>LOAD CURVES WITH REGENERATIVE EXTENSION VALVE DISABLED (EES)</b>



_____	<b>LOAD CURVES WITH REGENERATIVE EXTENSION VALVE ENABLED</b>
_____	<b>LOAD CURVES WITH REGENERATIVE EXTENSION VALVE DISABLED (EES)</b>



_____	<b>LOAD CURVES WITH REGENERATIVE EXTENSION VALVE ENABLED</b>
_____	<b>LOAD CURVES WITH REGENERATIVE EXTENSION VALVE DISABLED (EES)</b>



# HC801 TECHNICAL SHEET

## LOAD DIAGRAM E8J4

